

# Concrete Overlay Accelerator Installation Guide

## PRODUCT DESCRIPTION

Concrete Overlay Accelerator is a proprietary powder blend designed to increase the set times of VBP Kwik-Top, Versa-Crete overlays. Concrete Accelerator is designed to be used in colder climates where long set times would be prohibitive.

## **COVERAGE RATES AND PACKAGING**

Concrete Overlay Accelerator

1 Jar per 50 Lb Bag Sold in Jar Packs

## STEP 1) ADDITION OF ACCELERATOR PACKS

(Note: We do not recommend the use of Accelerator Packs to be used to speed up the drying process when applied at normal temperatures. Overly accelerated products will have reduced adhesion and other properties. Do not use accelerator at temperatures above 65°F or below 35°F.

## Adding Jar Pack

Add correct Concrete Overlay Accelerator to 1 bag mix of overlay material being.

#### Mixing

Follow the appropriate mixing instructions for the material being accelerated.

# Application

Follow the appropriate application instructions for the material being accelerated.

# STEP 2) CLEANUP

Follow the appropriate clean up instructions for the material being accelerated.

#### ADDITIONAL CAUTIONS AND RECOMENDATIONS

- Does not work with Metal Lathe Cement
- Do not force dry
- Dry times may vary dependant on temperature, humidity and mass size.
- For extreme cold temperatures you may allow an induction time in container to heat up material.
- Always wear protective clothing and equipment as required by OSHA and as necessary
- Read Material Safety Data Sheets before commencing work